



1. ALTERNATE COURSES A & B AS NEEDED UNTIL FULL HEIGHT OF WALL HAS BEEN REACHED
2. OCCASIONAL SAW-CUTTING OF UNITS WILL BE REQUIRED TO MAINTAIN PATTERN
3. H = FULL HEIGHT OF WALL



© 2018 Anchor Wall Engineering, LLC
 © and ™ Anchor Wall Systems, Inc.
www.anchorwall.com

This drawing is for illustrative purposes only and should not be used for construction without the signature of a registered professional engineer.

Brookshire™ Wall System

Inside Corners

Scale:	Drawn by:
1/2" = 1'-0"	SB
Date:	Drawing number:
9/14/2018	BR0906RE30