



**STEP 1 -** PLACE REINFORCEMENT SO LITTLE OR NO OVERLAP OCCURS IN THE RADIUS AREA. IF OVERLAP OCCURS, PLACE 2 TO 3 INCHES OF SAND BETWEEN THE REINFORCEMENT LAYERS.

**STEP 2 -** LAY THE NEXT COURSE OF BLOCK. MAKE A MARK ON THE BACK OF THE BLOCKS IN THE AREAS THAT ARE NOT REINFORCED. BACKFILL AND COMPACT THAT COURSE.

**STEP 3 -** PLACE REINFORCEMENT IN THE AREAS WHERE THE MARKS SHOW GAPS IN THE LOWER REINFORCEMENT PATTERN. CONTINUE NORMAL WALL CONSTRUCTION, REPEATING THESE STEPS AS NEEDED.

**NOTES:**

1. MINIMUM RADIUS INFORMATION:
  - A. INSIDE RADIUS: 8.0 FT TO FACE OF BOTTOM COURSE
  - B. OUTSIDE RADIUS: 4.0 FT TO BACK OF TOP COURSE
2. GRID LENGTH (L) PER DESIGN
3. REPEAT STEPS AS NEEDED TO FULL HEIGHT OF WALL



© 2018 Anchor Wall Engineering, LLC  
 © and ™ Anchor Wall Systems, Inc.  
[www.anchorwall.com](http://www.anchorwall.com)

This drawing is for illustrative purposes only and should not be used for construction without the signature of a registered professional engineer.

Brookshire™ Wall System

Curve Details

Scale:	Drawn by:
3/8" = 1'-0"	SB
Date:	Drawing number:
9/14/2018	BR0906RE27