



**BELGARD**  
PAVES THE WAY™

# ARTFORMS™

MODULAR PANEL SYSTEM



**IDEA BOOK**

# TABLE OF CONTENTS

<p>1.</p>  <p><b>BENCH &amp; PLANTER</b></p>	<p>6.</p>  <p><b>LONG BBQ</b></p>	<p>11.</p>  <p><b>LARGE COUNTER</b></p>	<p>16.</p>  <p><b>RECESSED RECTANGULAR GAS FIRE PIT</b></p>	<p>21.</p>  <p><b>PRIVACY WALL WITH BENCH</b></p>
<p>2.</p>  <p><b>CORNER BENCH &amp; PLANTER</b></p>	<p>7.</p>  <p><b>L-SHAPE BBQ</b></p>	<p>12.</p>  <p><b>LUXURY COUNTER &amp; BAR</b></p>	<p>17.</p>  <p><b>RECTANGULAR GAS FIRE PIT</b></p>	<p>22.</p>  <p><b>PRIVACY WALL WITH PLANTER</b></p>
<p>3.</p>  <p><b>BENCH &amp; VERTICAL PLANTER</b></p>	<p>8.</p>  <p><b>CORNER BBQ &amp; PIZZA GRILL</b></p>	<p>13.</p>  <p><b>RECESSED WOOD FIRE PIT</b></p>	<p>18.</p>  <p><b>SQUARE PLANTER</b></p>	<p>23.</p>  <p><b>PRIVACY WALL WITH VERTICAL PLANTER</b></p>
<p>4.</p>  <p><b>SMALL BBQ</b></p>	<p>9.</p>  <p><b>BBQ WITH LUXURY COUNTER &amp; BAR</b></p>	<p>14.</p>  <p><b>RECESSED GAS FIRE PIT</b></p>	<p>19.</p>  <p><b>RECTANGULAR PLANTER</b></p>	<p>24.</p>  <p><b>RAISED GARDEN</b></p>
<p>5.</p>  <p><b>MEDIUM BBQ</b></p>	<p>10.</p>  <p><b>COUNTER &amp; BAR</b></p>	<p>15.</p>  <p><b>GAS FIRE PIT</b></p>	<p>20.</p>  <p><b>VERTICAL PLANTER</b></p>	<p>25.</p>  <p><b>CORNER MULTILEVEL RAISED GARDEN</b></p>

# TABLE OF CONTENTS

26.



**MULTILEVEL RAISED GARDEN**

28.



**L-SHAPE BENCH WITH  
VERTICAL PLANTER**

30.



**HIGH TOP GAS FIREPIT**

27.



**FIREPLACE WITH BENCH  
& WOOD PERGOLA**

29.



**BBQ WITH BENCH &  
VERTICAL PLANTER**

31.




**CORNER BENCH & FIRE PIT**


# 1. BENCH & PLANTER



INTERIOR VIEW




## REQUIRED PANELS




**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.


FRONT VIEW



TOP VIEW



## REQUIRED HARDWARE




**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

# 2. CORNER BENCH & PLANTER



INTERIOR VIEW




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

## REQUIRED PANELS


	18 x 36 PANEL	<b>8x</b>
	18 x 36 PANEL	<b>8x</b>
	6 x 36 PANEL	<b>0x</b>
	6 x 36 PANEL	<b>0x</b>

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW



TOP VIEW



## REQUIRED HARDWARE

	ANCHOR SLIDE AND NUT	<b>74x</b>
	JOINING PLATE	<b>16x</b>
	OUTER CORNER	<b>20x</b>
	INNER CORNER	<b>0x</b>
	STRETCHER	<b>1x</b>


**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

# 3. BENCH & VERTICAL PLANTER




## INTERIOR VIEW

WOOD FRAME  
REFER TO PAGE 18 OF THE  
ARTFORMS INSTALLATION  
GUIDE




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

## REQUIRED PANELS




**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.


## FRONT VIEW



## TOP VIEW



## REQUIRED HARDWARE




**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

# 4. SMALL BBQ



### INTERIOR VIEW



**NOTE:** In DETAIL A, 7" height is related to a countertop thickness of 1".

⊗ Cut panel(s) according to the BBQ manufacturer's specifications for ventilation.


**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

### REQUIRED PANELS


	7x
	3x
	0x
	1x

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

### FRONT VIEW



### TOP VIEW



### REQUIRED HARDWARE


	ANCHOR SLIDE AND NUT	40x
	JOINING PLATE	12x
	OUTER CORNER	8x
	INNER CORNER	0x
	STRETCHER	0x

**IMPORTANT:** It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.



# 5. MEDIUM BBQ



## INTERIOR VIEW




## REQUIRED PANELS


	18 x 36 PANEL	<b>5x</b>
	18 x 36 PANEL	<b>6x</b>
	6 x 36 PANEL	<b>0x</b>
	6 x 36 PANEL	<b>2x</b>

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

## FRONT VIEW



## TOP VIEW



## REQUIRED HARDWARE


	ANCHOR SLIDE AND NUT	<b>48x</b>
	JOINING PLATE	<b>10x</b>
	OUTER CORNER	<b>14x</b>
	INNER CORNER	<b>0x</b>
	STRETCHER	<b>0x</b>

**IMPORTANT:** It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.

# 6. LONG BBQ



### INTERIOR VIEW




### REQUIRED PANELS


- 5x**
- 8x**
- 2x**
- 0x**

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

### FRONT VIEW



### TOP VIEW




### REQUIRED HARDWARE


- 56x**
- 14x**
- 14x**
- 0x**
- 0x**

**IMPORTANT:** It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.

# 7. L-SHAPE BBQ



INTERIOR VIEW



**NOTE:** In DETAIL A, 7" height is related to a countertop thickness of 1".

⊕ Cut panel(s) according to the BBQ manufacturer's specifications for ventilation.

**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

REQUIRED PANELS


- 9x
- 11x
- 0x
- 0x

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW



TOP VIEW



REQUIRED HARDWARE


- ANCHOR SLIDE AND NUT 76x
- JOINING PLATE 26x
- OUTER CORNER 10x
- INNER CORNER 2x
- STRETCHER 1x

**IMPORTANT:** It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.

# 8. CORNER BBQ & PIZZA GRILL




INTERIOR VIEW




REQUIRED PANELS

- 10x
  - 18x
  - 0x
  - 0x
- IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW



TOP VIEW






REQUIRED HARDWARE

- ANCHOR SLIDE AND NUT 110x
- JOINING PLATE 30x
- OUTER CORNER 21x
- INNER CORNER 4x
- STRETCHER 1x

**IMPORTANT:** It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.




**TOTAL WEIGHT** (PANELS & HARDWARE) **3977 Lbs**

# 8. CORNER BBQ & PIZZA GRILL



**IMPORTANT:** It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.

# BBQ WITH LUXURY COUNTER & BAR



**REQUIRED PANELS**

- A** 18 x 36 PANEL **10x**
- B** 18 x 36 PANEL **23x**
- C** 6 x 36 PANEL **4x**
- D** 6 x 36 PANEL **5x**




**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

**REQUIRED HARDWARE**

- ANCHOR SLIDE AND NUT** **150x**
- JOINING PLATE** **54x**
- OUTER CORNER** **22x**
- INNER CORNER** **6x**
- STRETCHER** **0x**

**IMPORTANT:** It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.

# BBQ WITH LUXURY COUNTER & BAR





**IMPORTANT:** It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.

# 10. COUNTER & BAR



## INTERIOR VIEW




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

## REQUIRED PANELS

- 4x**
- 8x**
- 4x**
- 3x**


**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

## FRONT VIEW




## TOP VIEW

18 x 36 PANELS



6 x 36 PANELS



## REQUIRED HARDWARE


- 76x**
- 34x**
- 4x**
- 0x**
- 0x**

**TOTAL WEIGHT (PANELS & HARDWARE) 1968 Lbs**

# 11. LARGE COUNTER




INTERIOR VIEW




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

## REQUIRED PANELS




**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.


FRONT VIEW



TOP VIEW



## REQUIRED HARDWARE




**TOTAL WEIGHT (PANELS & HARDWARE) 1815 Lbs**

# 12. LUXURY COUNTER & BAR



INTERIOR VIEW

For more details see next page




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

## REQUIRED PANELS

- CLOSED END**  
18 x 36 PANEL **6x**
- CLOSED END**  
18 x 36 PANEL **11x**
- CLOSED END**  
6 x 36 PANEL **4x**
- CLOSED END**  
6 x 36 PANEL **5x**


**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW




TOP VIEW

18 x 36 PANELS



6 x 36 PANELS







## REQUIRED HARDWARE

- ANCHOR SLIDE AND NUT** **108x**
- JOINING PLATE** **42x**
- OUTER CORNER** **12x**
- INNER CORNER** **0x**
- STRETCHER** **0x**

**TOTAL WEIGHT (PANELS & HARDWARE)** **2934 Lbs**

# 12. LUXURY COUNTER & BAR


EXPLODED VIEW



# 13. RECESSED WOOD FIRE PIT





INTERIOR VIEW




**NOTE:** The panels 18 x 36 are glued with 6 x 36 using CONSTRUCTION GLUE or STRUCTURE BOND

## REQUIRED PANELS


	18 x 36 PANEL	<b>4x</b>
	18 x 36 PANEL	<b>0x</b>
	6 x 36 PANEL	<b>4x</b>
	6 x 36 PANEL	<b>0x</b>

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW



TOP VIEW



## REQUIRED HARDWARE

	ANCHOR SLIDE AND NUT	<b>16x</b>
	JOINING PLATE	<b>0x</b>
	OUTER CORNER	<b>8x</b>
	INNER CORNER	<b>0x</b>
	STRETCHER	<b>0x</b>


**IMPORTANT:** It is recommended to follow the burner manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Metal liner plate and accessories are not included.

# 14. RECESSED GAS FIRE PIT



## INTERIOR VIEW

The 30 x 30 burner pan is sitting directly on the ARTFORMS hardware, on the corner's brackets.



⊙ Cut panel(s) according to the burner manufacturer's specifications for ventilation.


**NOTE:** The panels 18 x 36 are glued with 6 x 36 using CONSTRUCTION GLUE or STRUCTURE BOND

## REQUIRED PANELS


	18 x 36 PANEL	<b>4x</b>
	18 x 36 PANEL	<b>0x</b>
	6 x 36 PANEL	<b>4x</b>
	6 x 36 PANEL	<b>0x</b>

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

## FRONT VIEW



## TOP VIEW



## REQUIRED HARDWARE

	ANCHOR SLIDE AND NUT	<b>16x</b>
	JOINING PLATE	<b>0x</b>
	OUTER CORNER	<b>8x</b>
	INNER CORNER	<b>0x</b>
	STRETCHER	<b>0x</b>


**IMPORTANT:** It is recommended to follow the burner manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan and accessories are not included. PROPOSED MODEL: Linzel SQUARE Burner 30" PLATE KIT

**TOTAL WEIGHT (PANELS & HARDWARE)** **683 Lbs**

# 15. GAS FIRE PIT



INTERIOR VIEW




⊕ Add 0.5" thick PLASTIC SHIMS for ventilation

## REQUIRED PANELS


- CLOSED END  
 18 x 36 PANEL **4x**
- 18 x 36 PANEL **0x**
- CLOSED END  
 6 x 36 PANEL **0x**
- 6 x 36 PANEL **0x**

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW



TOP VIEW



## REQUIRED HARDWARE

- ANCHOR SLIDE AND NUT **16x**
- JOINING PLATE **0x**
- OUTER CORNER **8x**
- INNER CORNER **0x**
- STRETCHER **0x**


**IMPORTANT:** It is recommended to follow the firekit manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan and accessories are not included. PROPOSED MODEL: Linzel SQUARE Burner 30" PLATE KIT

**TOTAL WEIGHT (PANELS & HARDWARE)** **535 Lbs**

# RECESSED RECTANGULAR GAS FIRE PIT



### INTERIOR VIEW




### REQUIRED PANELS

- CLOSED END  
 18 x 36 PANEL **4x**
- 18 x 36 PANEL **3x**
- CLOSED END  
 6 x 36 PANEL **4x**
- 6 x 36 PANEL **2x**


**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

### FRONT VIEW




### TOP VIEW

#### WITHOUT TOP PANELS



#### WITH TOP PANELS



### REQUIRED HARDWARE

- ANCHOR SLIDE AND NUT **48x**
- JOINING PLATE **8x**
- OUTER CORNER **16x**
- INNER CORNER **0x**
- STRETCHER **0x**


**IMPORTANT:** It is recommended to follow the firekit manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan and accessories are not included. PROPOSED MODEL: Linzel SQUARE Burner 46 x 17 PLATE KIT

**TOTAL WEIGHT (PANELS & HARDWARE) 1130 Lbs**

# 17. RECTANGULAR GAS FIRE PIT




## INTERIOR VIEW




- ⊙ Cut panel(s) according to the burner manufacturer's specifications for ventilation.
- ⊙ Add 0.5" thick PLASTIC SHIMS for ventilation

## REQUIRED PANELS




**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

## FRONT VIEW




## TOP VIEW


### WITHOUT TOP LAYER



### WITH TOP LAYER



## REQUIRED HARDWARE




**IMPORTANT:** It is recommended to follow the firekit manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner plate and accessories are not included. PROPOSED MODEL: Linzel H-STYLE Burner 46 x 15 PLATE KIT

**TOTAL WEIGHT (PANELS & HARDWARE)** **880 Lbs**

# 18. SQUARE PLANTER



INTERIOR VIEW




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

## REQUIRED PANELS


	18 x 36 PANEL	<b>0x</b>
	18 x 36 PANEL	<b>4x</b>
	6 x 36 PANEL	<b>4x</b>
	6 x 36 PANEL	<b>0x</b>

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW



TOP VIEW



## REQUIRED HARDWARE

	ANCHOR SLIDE AND NUT	<b>40x</b>
	JOINING PLATE	<b>8x</b>
	OUTER CORNER	<b>8x</b>
	INNER CORNER	<b>0x</b>
	STRETCHER	<b>0x</b>



**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

**TOTAL WEIGHT (PANELS & HARDWARE)** **804 Lbs**

# 19. RECTANGULAR PLANTER




INTERIOR VIEW




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

## REQUIRED PANELS




**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.


FRONT VIEW



TOP VIEW




## REQUIRED HARDWARE



**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

**TOTAL WEIGHT (PANELS & HARDWARE)** **1209 Lbs**



# 20. VERTICAL PLANTER



**REQUIRED PANELS**

	18 x 36 PANEL	<b>4x</b>
	18 x 36 PANEL	<b>6x</b>
	6 x 36 PANEL	<b>4x</b>
	6 x 36 PANEL	<b>2x</b>

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.



**REQUIRED HARDWARE**

	ANCHOR SLIDE AND NUT	<b>62x</b>
	JOINING PLATE	<b>12x</b>
	OUTER CORNER	<b>18x</b>
	INNER CORNER	<b>0x</b>
	STRETCHER	<b>1x</b>



**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

**TOTAL WEIGHT (PANELS & HARDWARE)** **1765 Lbs**

# 21. PRIVACY WALL WITH BENCH




## INTERIOR VIEW




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers.

## REQUIRED PANELS




**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.


## FRONT VIEW



## TOP VIEW



## REQUIRED HARDWARE




**TOTAL WEIGHT**  
(PANELS & HARDWARE) **740 Lbs**

# PRIVACY WALL WITH PLANTER



INTERIOR VIEW




REQUIRED PANELS


- CLOSED END  
 18 x 36 PANEL **0x**
- 18 x 36 PANEL **6x**
- CLOSED END  
 6 x 36 PANEL **4x**
- 6 x 36 PANEL **2x**

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW



TOP VIEW




REQUIRED HARDWARE

- ANCHOR SLIDE AND NUT **43x**
- JOINING PLATE **24x**
- OUTER CORNER **4x**
- INNER CORNER **0x**
- STRETCHER **0x**

**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

**TOTAL WEIGHT (PANELS & HARDWARE) 1206 Lbs**



# PRIVACY WALL WITH VERTICAL PLANTER



**REQUIRED PANELS**

	18 x 36 PANEL	<b>2x</b>
	18 x 36 PANEL	<b>8x</b>
	6 x 36 PANEL	<b>3x</b>
	6 x 36 PANEL	<b>3x</b>

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.



**REQUIRED HARDWARE**

	ANCHOR SLIDE AND NUT	<b>66x</b>
	JOINING PLATE	<b>12x</b>
	OUTER CORNER	<b>20x</b>
	INNER CORNER	<b>0x</b>
	STRETCHER	<b>1x</b>


**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

**TOTAL WEIGHT (PANELS & HARDWARE) 1667 Lbs**

# 24. RAISED GARDEN



## INTERIOR VIEW




## REQUIRED PANELS

	18 x 36 PANEL	<b>0x</b>
	18 x 36 PANEL	<b>10x</b>
	6 x 36 PANEL	<b>4x</b>
	6 x 36 PANEL	<b>6x</b>


**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

## FRONT VIEW




## TOP VIEW

### 18 x 36 PANELS



### 6 x 36 PANELS



## REQUIRED HARDWARE

	ANCHOR SLIDE AND NUT	<b>54x</b>
	JOINING PLATE	<b>18x</b>
	OUTER CORNER	<b>8x</b>
	INNER CORNER	<b>0x</b>
	STRETCHER	<b>1x</b>


**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

**TOTAL WEIGHT (PANELS & HARDWARE) 1986 Lbs**

# CORNER MULTILEVEL RAISED GARDEN



INTERIOR VIEW




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

**REQUIRED PANELS**


- 18 x 36 PANEL** **15x**
- 18 x 36 PANEL** **20x**
- 6 x 36 PANEL** **0x**
- 6 x 36 PANEL** **0x**

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW



TOP VIEW



**REQUIRED HARDWARE**

- ANCHOR SLIDE AND NUT** **153x**
- JOINING PLATE** **46x**
- OUTER CORNER** **20x**
- INNER CORNER** **4x**
- STRETCHER** **7x**


**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

**TOTAL WEIGHT (PANELS & HARDWARE)** **4937 Lbs**

# 26. MULTILEVEL RAISED GARDEN



INTERIOR VIEW




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

## REQUIRED PANELS


	18 x 36 PANEL	<b>22x</b>
	18 x 36 PANEL	<b>18x</b>
	6 x 36 PANEL	<b>0x</b>
	6 x 36 PANEL	<b>0x</b>

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW



TOP VIEW




## REQUIRED HARDWARE

	ANCHOR SLIDE AND NUT	<b>168x</b>
	JOINING PLATE	<b>48x</b>
	OUTER CORNER	<b>32x</b>
	INNER CORNER	<b>0x</b>
	STRETCHER	<b>2x</b>

**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

**TOTAL WEIGHT (PANELS & HARDWARE) 6058 Lbs**



# FIREPLACE WITH BENCH & WOOD PERGOLA



**REQUIRED PANELS**

	18 x 36 PANEL	<b>16x</b>
	18 x 36 PANEL	<b>34x</b>
	6 x 36 PANEL	<b>0x</b>
	6 x 36 PANEL	<b>0x</b>

**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.



**REQUIRED HARDWARE**

	ANCHOR SLIDE AND NUT	<b>210x</b>
	JOINING PLATE	<b>54x</b>
	OUTER CORNER	<b>44x</b>
	INNER CORNER	<b>4x</b>
	STRETCHER	<b>2x</b>

**IMPORTANT:** Other types of hardware (not included) may be required to make these assemblies (wood screws, concrete anchors, etc.). BELGARD is not responsible for any issue regarding other materials, accessories, other types of hardware, etc. We recommend to consulting an expert/engineer to validate installation of the wood posts of pergola.

**TOTAL WEIGHT (PANELS & HARDWARE)** **2315 Lbs**

# L-SHAPED BENCH & VERTICAL PLANTER




### INTERIOR VIEW

WOOD FRAME  
REFER TO PAGE 18  
OF THE ARTFORMS  
INSTALLATION GUIDE


INTEGRATING 4 x 4  
WOOD POST  
REFER TO PAGES 19 AND  
20 OF THE ARTFORMS  
INSTALLATION GUIDE

4 x 4 WOOD POST




**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

### REQUIRED PANELS




**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.


### FRONT VIEW



### TOP VIEW



### REQUIRED HARDWARE



**IMPORTANT:** Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

**TOTAL WEIGHT (PANELS & HARDWARE) 3615 Lbs**



# 30. HIGH TOP GAS FIRE PIT


Gas Option



Propane Option




## INTERIOR VIEW



Ⓞ Cut panel(s) according to the burner manufacturer's specifications for ventilation.


**NOTE:** Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

## REQUIRED PANELS




**IMPORTANT:** 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

## FRONT VIEW




## TOP VIEW


18 x 36 PANELS



6 x 36 PANELS



## REQUIRED HARDWARE




**IMPORTANT:** It is recommended to follow the FIREKIT manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan, countertop and accessories are not included.

**TOTAL WEIGHT (PANELS & HARDWARE) 1707 Lbs**






# 31. CORNER BENCH & FIRE PIT



**1.** Drill the concrete panel to install the Concrete Screw Anchors, and the wood post to install the Stainless Steel Screw.

**NOTE:**  
**X:** Stainless Steel Wood Screw Flat Head #10 x 2½"  
**Y:** Concrete screw anchor (Tapcon®) ¼ x 1¾ or ¾ x 1¾



4 x 4 WOOD POST


4 x 4 WOOD POST

**16 3/8**  
 (Install the 4 x 4 wood post at 16 3/8 from the ground to assemble the Inner Corner)


## VERTICAL & HORIZONTAL PLANTER BOX

**2.** OPTIONAL: LED strip can be inserted in the dovetail. Refer to page 16 of the ARTEX INSTALLATION GUIDE.

**4.** The panels 6 x 36 are glued using CONSTRUCTION GLUE or STRUCTURE BOND.



**3.** EXPLODED VIEW - BAR TABLE



**IMPORTANT:** It is recommended to follow the manufacturer's specifications for LED stripes and wire connections. Belgard is not responsible for the conformity of the LED strip inserts.

