



Design Notes:

1. Depth of subbase subject to site specific hydraulic and structural requirements. Contact Oldcastle Architectural for design assistance.
2. Paver dimensions subject to aspect and plan ratio requirements based on traffic loading.
3. Geotechnical engineer needs to balance structural stability and soil infiltration when recommending subgrade conditions.
4. Geotechnical engineer shall confirm type and thickness of geomembrane liner used is suitable for the application and aggregate types used.



belgard.com
877-235-4273
details@belgard.com

This drawing is for illustrative purposes only and should not be used for construction without the signature of a registered professional engineer.

Belgard Permeable Paving Detail - Full Infiltration
PICP Geomembrane Flow Dams for Sloped Conditions

Scale:	Drawn by:
1" = 1'-0"	JB
Date:	Drawing number:
1/23/2016	AQBV09