



Click on the title of your choice to see the detail page

SYSTEM OVERVIEW

INSTALLATION



SCAN HERE
TO SEE SOME
ARTFORMS™ BUILDS
IN BELGARD ROOMS

ARTFORMS™ | MODULAR PANEL SYSTEM



3

PARTS LIST - HARDWARE (STAINLESS STEEL)


ARTFORMS™ | MODULAR PANEL SYSTEM

Anchor Slide – ¼" x 20 stud & nut

2 x 1¼ x 1" (51 x 33 x 25 mm)

0.1 lbs (0.05 kg)

50 units/box




***Joining Plate**

8¼ x 2½ x 1½" (209 x 63 x 38 mm)

1 lbs (0.5 kg)

10 units/box




***Inner Corner**

9 x 6 x 2½" (232 x 155 x 63 mm)

1.5 lbs (0.7 kg)

10 units/box




***Outer Corner**

4 x 4 x 2½" (101 x 101 x 63 mm)

0.9 lbs (0.4 kg)

10 units/box




***Stretcher Bar**

36¾ x 1¼ x 1" (933 x 33 x 25 mm)

2 lbs (0.9 kg)

10 units/box




*** NOTE:** Can be sold separately.

TOOLS & SAFETY EQUIPMENT

ARTFORMS™ | MODULAR PANEL SYSTEM

REQUIRED TOOLS


Drill




Mallet




Measuring tape




Saw




Level




**Deep Hex Socket
7/16" with 1/4"
Drive**




**Socket Adaptor
1/4" Hex shank to
1/4" Drive**




Chipping Hammer



Bar Clamp (48")



Plastic shims



SAFETY EQUIPMENT


Safety boots




Gloves



Safety glasses




Mask





PLANTER BOX & BENCH




PLANTER BOX & PRIVACY WALL




RAISED GARDEN



* FIRE PIT



WATERFALL



FLOATING STEPS



* ARGENTINE GRILL ISLAND



* GRILL ISLAND



COUNTER ISLAND

ARTFORMS • IDEA BOOK




CLICK HERE
TO DISCOVER MORE
APPLICATIONS

*** IMPORTANT:** For all complementary appliances/accessories to the **Artforms panel system**, follow manufacturer's instructions/guidelines. Consult qualified services person/ experts to validate installations, repairs, safety recommendations and any other related topics.


MODULARITY - THE SYSTEM

ARTFORMS™ | MODULAR PANEL SYSTEM




18 x 36 x 3" PANEL





6 x 36 x 3" PANEL





**RECOMMENDED :
CUT IN THE MIDDLE OF
DOVETAIL**



ADJUSTMENT



ADJUSTABLE SLOT-HOLE



NOTE: It is recommended to design structures with overall dimensions using increments of 3" (76mm).

MODULARITY - REFERENCES

ARTFORMS™ | MODULAR PANEL SYSTEM

KITCHEN TABLE




FRONT VIEW

BAR TABLE



FRONT VIEW

SEATING



FRONT VIEW


SIDE VIEW

*** NOTE:** Maximum height of **36"** for planter box and **42"** for outdoor living structure. Any higher structure must be designed by an engineer.


PANEL CONFIGURATIONS

ARTFORMS™ | MODULAR PANEL SYSTEM




Coping can be used to hide the dovetails.





Coping optional.




Coping can be used to hide the dovetails.



*** IDEAL:**
This configuration uses equal number of panel A and panel B.



*** NOT OPTIMAL:**
This configuration uses panel A only.






*** NOT RECOMMENDED:**
This configuration uses panel B only and the dovetails are exposed. Use ideal configuration as shown above.

***IMPORTANT:** When planning configurations, consider the amount of panel A and panel B on a pallet. 18x36" panels are sold in pair/layer or in full pallet only. 6x36" panels are sold in layer or in full pallet only.




OUTER CORNER INSTALLATION

ARTFORMS™ | MODULAR PANEL SYSTEM

HORIZONTAL PANELS



VERTICAL PANELS







*** IMPORTANT:** Always use a minimum of 2 outer corner brackets per corner assembly.

► See Tips and Tricks from page 27 for more details.





INNER CORNER INSTALLATION

ARTFORMS™ | MODULAR PANEL SYSTEM

HORIZONTAL PANELS



VERTICAL PANELS






*** IMPORTANT:** Always use a minimum of 2 inner corner brackets per corner assembly.

► See Tips and Tricks from page 27 for more details.




JOINING PLATE INSTALLATION

ARTFORMS™ | MODULAR PANEL SYSTEM

HORIZONTAL PANELS



VERTICAL PANELS






*** IMPORTANT:** Always use a minimum of 2 joining plates when joining two parallel panels.

► See Tips and Tricks from page 27 for more details.

STRETCHER BAR INSTALLATION


ARTFORMS™ | MODULAR PANEL SYSTEM

HORIZONTAL PANELS




The stretcher bar provides structure to keep 2 sets of facing panels in parallel alignment. It is recommended to attach the stretcher bar to the joining plate every 6ft (1.8m). Place it at 1/3 of the total height from the bottom of assembly.

The stretcher bar must be cut to fit distance between 2 sets of panels.



NOTE: The stretcher bar can be extended.




► See Tips and Tricks from page 27 for more details.

STRETCHER BAR INSTALLATION


ARTFORMS™ | MODULAR PANEL SYSTEM

VERTICAL PANELS



The stretcher bar provides structure to keep 2 sets of facing panels in parallel alignment. It is recommended to attach the stretcher bar to the joining plate every 3ft (0.9m). Place it at approximately 1/3 of the total height from the bottom of assembly.

The stretcher bar must be cut to fit distance between 2 sets of panels.




► See Tips and Tricks from page 27 for more details.

6 X 36 PANEL - COPING INSTALLATION (MECHANICALLY FIXED)




ARTFORMS™ | MODULAR PANEL SYSTEM



18 x 36 x 3" HORIZONTAL PANELS




18 x 36 x 3" VERTICAL PANELS




► See Tips and Tricks from page 27 for more details.

6 X 36 PANEL - COPING INSTALLATION (FIXED WITH ADHESIVE)

ARTFORMS™ | MODULAR PANEL SYSTEM




**AFFIX COPING WITH
CONSTRUCTION GLUE
OR TECHNISEAL® Techni-
seal® Structure Bond™**




6 X 36 PANEL - ACCENT INSTALLATION

ARTFORMS™ | MODULAR PANEL SYSTEM


6 x 36 x 3" PANEL








18 x 36 x 3" HORIZONTAL PANEL



6 x 36 x 3" PANEL



18 x 36 x 3" VERTICAL PANEL







*** IMPORTANT:** Always use a minimum of 2 joining plates when joining 6x36 panel with 18x36 panel
 ▶ See Tips and Tricks from page 27 for more details.



INTEGRATING WOOD

ARTFORMS™ | MODULAR PANEL SYSTEM




BENCH



	x24
	x 8
	x 4
	x 6
A/B	
	TREATED WOOD SCREW #8 OR #10



INSTALL THE
HARDWARE
ACCORDING
TO WOOD
SIZE




SECTION VIEW

► See Tips and Tricks from page 27 for more details.




INTEGRATING 4 X 4" WOOD POSTS

ARTFORMS™ | MODULAR PANEL SYSTEM

HORIZONTAL PANELS



VERTICAL PANELS



X=Stainless Steel Wood Screw Flat Head #10 x 2½"

V=Stainless Steel Lag screws 1/4 x 2½" or 5/16 x 2½"

Y=Treated Concrete Anchor (Tapcon®) 1/4"x1¾" or 3/16"x1¾" Z=Stainless Steel Oversized Washer 5/16"


IMPORTANT: Other types of hardware (not included) may be required to make these assemblies (wood screws, concrete anchors, etc.).

BELGARD is not responsible for any issue regarding other materials, accessories, other types of hardware, etc. *We recommend consulting an expert or engineer to determine the design limitations of the screen panels based on wind loads.*


INTEGRATING 4 X 4" WOOD POSTS

ARTFORMS™ | MODULAR PANEL SYSTEM

HORIZONTAL PANELS



VERTICAL PANELS



X=Stainless Steel Wood Screw Flat Head #10 x 2½"

V=Stainless Steel Lag screws 1/4 x 2½" or 5/16 x 2½"

Y=Treated Concrete Anchor (Tapcon®) 1/4"x1¾" or 3/16"x1¾" Z=Stainless Steel Oversized Washer 5/16"


IMPORTANT: Other types of hardware (not included) may be required to make these assemblies (wood screws, concrete anchors, etc.).

BELGARD is not responsible for any issue regarding other materials, accessories, other types of hardware, etc. *We recommend consulting an expert or engineer to determine the design limitations of the screen panels based on wind loads.*


INTEGRATING 4 X 4" WOOD POSTS

ARTFORMS™ | MODULAR PANEL SYSTEM

HORIZONTAL PANELS




VERTICAL PANELS




INTEGRATING METAL POSTS

HORIZONTAL PANELS



VERTICAL PANELS



X=Stainless Steel Wood Screw Flat Head #10 x 2½"

V=Stainless Steel Lag screws 1/4 x 2½" or 5/16 x 2½"

Y=Treated Concrete Anchor (Tapcon®) 1/4"x1¾" or 3/16"x1¾" Z=Stainless Steel Oversized Washer 5/16"


IMPORTANT: Other types of hardware (not included) may be required to make these assemblies (wood screws, concrete anchors, etc.).

BELGARD is not responsible for any issue regarding other materials, accessories, other types of hardware, etc. We recommend consulting an expert or engineer to determine the design limitations of the screen panels based on wind loads.


BASE PREPARATION

ARTFORMS™ | MODULAR PANEL SYSTEM


ON EXISTING PATIO




ON COMPACTED FOUNDATION USING STARTER UNIT



ON POURED CONCRETE FOUNDATION



ON COMPACTED FOUNDATION





- | | |
|---|---------------------------------------|
| A- ARTFORMS Panels | E- Soil |
| B- Slab or Paver | F- Starter Unit/ Slab or Paver |
| C- Bedding Sand 1" (25mm) | G- Reinforced Poured Concrete |
| D- Compacted aggregates 8" (200mm) minimum | Foundation 2" (50mm) minimum |
| | H- Opening for drainage |

IMPORTANT: Provide adequate drainage and adjust according to soil type. Maximum height of **36"** for planter box and **42"** for outdoor living structure. Any higher structure must be designed by an engineer. Dimensions and information above are general recommendations only. Contact experts or engineers to validate the base preparation, the drainage, the plants & roots growth/management. The use of plastic shims can facilitate the installation of **Artforms** panels in order to adapt to the slope of the site.


PLANTER BOX DETAIL

ARTFORMS™ | MODULAR PANEL SYSTEM

ON COMPACTED FOUNDATION



Recommended:
Place insulated panels to protect plants from cold conditions.



Recommended:
Place a cement board on top of the Artforms hardware to reduce the amount of infill material.


A- ARTFORMS Panels
H- Opening for drainage
I- Geotextile membrane
J- Insulated panel

K- Structural Water Resistant Panel


IMPORTANT: Provide adequate drainage and adjust according to soil type. Maximum height of **36"** for planter box and **42"** for outdoor living structure. Any higher structure must be designed by an engineer. Dimensions and information above are general recommendations only. Contact experts or engineers to validate the base preparation, the drainage, the plants & roots growth/management. The use of plastic shims can facilitate the installation of **Artforms** panels in order to adapt to the slope of the site.

ROOFTOP APPLICATIONS


ARTFORMS™ | MODULAR PANEL SYSTEM



PLANTER BOX WITH HORIZONTAL
PANELS SITTING ON SLABS/TILES - SECTION VIEW




PLANTER BOX WITH VERTICAL
PANELS SITTING ON SLABS/TILES
- SECTION VIEW



PLANTER BOX AND BENCH SITTING ON SLABS/TILES
- SECTION VIEW


- A- ARTFORMS** Panels
- B-** Slab or Tile
- H-** Opening for drainage
- I -** Geotextile Membrane
- K-** Structural Water Resistant Panel
- L-** Pedestal
- P-** Treated Wood Structure




IMPORTANT: Contact experts or engineers for proper staging on existing rooftop surfaces.

ROOFTOP APPLICATIONS

ARTFORMS™ | MODULAR PANEL SYSTEM





PLANTER BOX SITTING ON PEDESTALS - SECTION VIEW




BENCH AND PLANTER BOX SITTING ON PEDESTALS - SECTION VIEW


- A- ARTFORMS** Panels
- B-** Slab or Tile
- H-** Opening for drainage
- I -** Geotextile Membrane
- K-** Structural Water Resistant Panel
- L-** Pedestal
- O-** Stretcher bar
- P-** Treated Wood Structure




IMPORTANT: Contact experts or engineers for proper staging on existing rooftop surfaces.




Place pallet close to installation area




Recommended handling tool




Recommended handling tool



Lift with two people




Mechanical lifting device




Use hand trolley if necessary


#1 [General]: Ensure that all the panels are in place, levelled & aligned before fully tightening the hardware in the corners at the end of the installation.




#2 [General]: Pre-assemble hardware to facilitate its installation. Ensure that all the panels are in place, levelled & aligned before fully tighten the hardware at the end of the installation.




#3 [Anchor slide]: Insert anchor slides from the bottom of the closed end panel (panel A) prior to its assembly.




#4 [Anchor slide]: Insert the anchor slide. Lock it into place to prevent it from sliding down and to facilitate assembly.




#5 [Joining plate]: Use the larger tab of the joining plate when it is perpendicular or parallel to the dovetail slot.




#6 [Joining plate]: Only when the joining plate is perpendicular to the dovetail, the small tab can be used. Otherwise, the overlapping surface will be too narrow.



#7 [Stretcher bar]: Use the stretcher bar when it is perpendicular to the dovetail. Otherwise, the overlapping surface will be too narrow.




#8 [Bar Clamp]: Use the bar clamp to keep the panels in place and to facilitate the hardware installation.




TIPS AND TRICKS

ARTFORMS™ | MODULAR PANEL SYSTEM


#9 [General]: If required, it is possible to secure the **ARTFORMS** structure to the existing base by placing the hardware against it. Contact experts/engineers to validate the structure and any related matters.



#11 [General]: In the case you forgot to place the anchor slides when the closed end panels (panel A) have already been assembled, use a chipping hammer to break a small section of the dovetail slot to insert the anchor slide.




#10 [General]: If the side to side panels have a different thickness, use plastic shims to align the front face.




#12 [General]: If assembling the hardware on the side of the panel without dovetails, drill the panel and use a concrete screw anchor (Tapcon®).

NOTE: Y: Concrete screw anchor (Tapcon®) ¼" x 1 ¾" or ⅜" x 1 ¾"




#13 [Custom angle]: In case of an **OUTER OBTUSE ANGLE CORNER** (more than 90°) cut the both panels to the appropriate/needed angle. Use construction glue or Techniseal® Structure Bond™ to solidify the corners.



OUTER OBTUSE ANGLE CORNER

A	B	C	D	E
100 °	80 °	50 °	50 °	2.5" (63 mm)
110 °	70 °	55 °	55 °	2" (50 mm)
120 °	60 °	60 °	60 °	1.7" (42 mm)
130 °	50 °	65 °	65 °	1.35" (35 mm)
140 °	40 °	70 °	70 °	1" (25 mm)
150 °	30 °	75 °	75 °	0.8" (20 mm)
160 °	20 °	80 °	80 °	0.5" (15 mm)
170 °	10 °	85 °	85 °	0.25" (7 mm)


#14 [Custom angle]: In case of an **INNER OBTUSE ANGLE CORNER** (more than 90°) cut the both panels to the appropriate/needed angle. Use construction glue or Techniseal® Structure Bond™ to solidify the corners.



INNER OBTUSE ANGLE CORNER

A	B	C	D	E
100 °	80 °	50 °	50 °	2.5" (63 mm)
110 °	70 °	55 °	55 °	2" (50 mm)
120 °	60 °	60 °	60 °	1.7" (42 mm)
130 °	50 °	65 °	65 °	1.35" (35 mm)
140 °	40 °	70 °	70 °	1" (25 mm)
150 °	30 °	75 °	75 °	0.8" (20 mm)
160 °	20 °	80 °	80 °	0.5" (15 mm)
170 °	10 °	85 °	85 °	0.25" (7 mm)


#15 [Custom angle]: In case of an **OUTER ACUTE ANGLE CORNER** (less than 90°) cut just one panel to the appropriate/needed angle. Use construction glue or Techniseal® Structure Bond™ to solidify the corners.



OUTER ACUTE ANGLE CORNER

A	B	C	D	E
135 °	45 °	45 °	45 °	2.9" (75 mm)
125 °	55 °	55 °	35 °	2" (50 mm)
115 °	65 °	65 °	25 °	1.3" (35 mm)
105 °	75 °	75 °	15 °	0.8" (20 mm)

#16 [Custom angle]: In case of an **INNER ACUTE ANGLE CORNER** (less than 90°) cut just one panel to the appropriate/needed angle. Use construction glue or Techniseal® Structure Bond™ to solidify the corners.




INNER ACUTE ANGLE CORNER

A	B	C	D	E
135 °	45 °	45 °	45 °	2.9" (75 mm)
125 °	55 °	55 °	35 °	2" (50 mm)
115 °	65 °	65 °	25 °	1.3" (35 mm)
105 °	75 °	75 °	15 °	0.8" (20 mm)

TIPS AND TRICKS

ARTFORMS™ | MODULAR PANEL SYSTEM

#17 [General]: Make a cut on the top & bottom of the **ARTFORMS** panel to install the venting trap. It is recommended to follow the venting manufacturer's specifications for ventilation and clearances. Secure the venting trap with adhesive or screws.





AN OLDCASTLE® APG OUTDOOR BRAND